

OPERATING MANUAL



- Characteristic: 1. Pilot operated piston construction with low power consumption
2. Seal serves longtime at steam ambient
3. Used for long-time working in pipeline system

Medium: Steam, Hot Water, Oil, etc.

Temperature: PTFE Seal: -10°C to 180°C
Graphite Seal: -10°C to 300°C

Pressure: 0.05Mpa~1.6Mpa NC

Port Size: 1/2", 3/4", 1", 1¼", 1½", 2"

Port Thread: G, BSP, NPT



Orifice(mm): 12, 15, 20, 25, 32, 40, 50

Voltage: DC-12V, 24V, 36V
AC-24V, 120V, 240V/60Hz; 110V, 220V/50Hz

Tolerance: ±10%

Coils: Y21H, 28VA(AC), 22W(DC), Ip65, 100%ED


- Material: Body - Brass or stainless steel
- Seal - PET
- Armature Tube - Stainless Steel304
- Plunger - Stainless Steel 430F
- Stop - SS 403F
- Springs - SS 304
- Shading Rings - Stainless Steel 304



Coils Parameters

Model	Picture	Voltage	Motor Power	Protection Class	Available For	Outline Size Drawing
Y21B		1.AC220V 2.AC110V 3.AC24V 1.DC24V 2.DC12V 3.DC6V <i>Special Voltage Can Be Customized</i>	18VA 16W	IP65	DN10 DN15 DN20 DN25	
Y51B		1.AC220V 2.AC110V 3.AC24V 1.DC24V 2.DC12V 3.DC6V <i>Special Voltage Can Be Customized</i>	70VA 50W	IP65	DN32 DN40 DN50	

Determine Valve Body Code




EXMAPLE:HK08 SERIES, NC, 25MM ORIFICE, 1"G, STAINLESS BODY, PET SEAL, COIL S21H, AC220V, DIN

Technical Parameters

Size	Port Size	Orifice mm	Cv	Min Pressure	Max Presuure	Operating Temperature	Weight
HK10-12	3/8"	12	4.5	0.05MPa	1.6MPa	PTFE: -10°C~180°C Graphite: -10°C~300°C	
HK10-15	1/2"	15	4.5	0.05MPa	1.6MPa		
HK10-20	3/4"	20	9.3	0.05MPa	1.6MPa		
HK10-25	1"	25	12	0.05MPa	1.6MPa		
HK10-32	1-1/4"	32	24	0.05MPa	1.6MPa		
HK10-40	1-1/2"	40	29	0.05MPa	1.6MPa		
HK10-50	2"	50	48	0.05MPa	1.6MPa		
HK10F-25	1"	25	12	0.05MPa	1.6MPa		
HK10F-32	1-1/4"	32	24	0.05MPa	1.6MPa		
HK10F-40	1-1/2"	40	29	0.05MPa	1.6MPa		
HK10F-50	2"	50	48	0.05MPa	1.6MPa		


Outline Size Drawing

Hk10 Thread



阀体	A	B	C
DN15	73	48	176
DN20	83	60	189.5
DN25	100	72	189.5
DN32	130	96	214
DN40	130	96	214
DN50	155	122	228

Hk10 Flange




阀体	A	B	C	D	n-φd
DN15					
DN20					
DN25					
DN32					
DN40					
DN50					

Safety instructions before starting

1. Check the compatibility of the medium used, temperature and other operating conditions with the materials and specifications of the product. It is the responsibility of the user to select the right product for the application.
2. Solenoid valves can only be used with clean liquids or gases. It is recommended to install a filter before the solenoid valve.
3. Never exceed the limits for pressure, temperature or voltage as indicated on the product and/or in the technical documentation.
4. The temperature of a solenoid valve coil can rise during operation; this is normal. Overheating will cause smoke and a burning smell. In this case, the power supply must immediately be disconnected.

▲ It is recommended to install the solenoid in vertical position with the coil facing upwards. This reduces the probability of the collection of debris in the solenoid valve.



Installation Instruction

1. The solenoid valve can be used in combination with clean liquids or gases. Make sure that the pipe may contain dirt before installing the valve. It is recommended to install a filter (500 µm) before the solenoid valve.
2. Be aware of the direction of flow of the medium when installing the valve. Solenoid valves with an arrow on the housing must be connected in the indicated direction. The pipes on both sides of the valve must be securely fastened. Use a wrench for both valve and pipe while tightening to prevent unnecessary stresses in the system. The solenoid valve must be fixed via the provided connection points. Only exert force at the designated areas on the body such as the hexagon; never to the coil or armature. Avoid vibration in the pipes. Use a suitable sealant for threaded connections of the solenoid valve. Avoid the entry of thread sealing material in the valve, this can lead to malfunctioning of the valve.

Common faults and inspection, troubleshooting

Problem	Solution
Valve fails to operate	1. Check electrical supply with voltmeter. Voltage must agree with nameplate rating.
	2. Check coil with ohmmeter for shorted or opened coil.
	3. Make sure that pressure complies with nameplate rating.
The valve is sluggish or inoperative - electrical supply and pressure check out	1. Disassemble valve; clean out extraneous matter. The plunger must be free to move without binding.
	2. If a diaphragm design, check the diaphragm for tears and/or clogged or obstructed bleed hole or pilot orifice. Torn diaphragm must be replaced.
	3. Check all springs. If broken, replace.
External leakage at sleeve flange or joint between body and cover	Check that the sleeve and/or cover screws are torqued to specifications. If leakage persists, replacement of diaphragm assembly or flange O-ring may be required and/or bodies or covers with damaged sealing surfaces may have to be replaced.
External leakage at speed control device	Check O-rings for damage and replace if necessary.
Internal leakage	1. Disassemble valve, remove extraneous matter, and clean parts in a mild soap and water solution.
	2. Examine diaphragm sealing surface for dirt. Remove all foreign particles. Examine orifice for nicks. Damaged parts must be repaired or replaced.
	3. Check plunger return spring. Replace if broken.
Chatter or buzz sound when energized	1. Remove power from the coil.
	2. Inspect the plunger and sleeve for excessive wear or contamination.