

## OPERATING MANUAL



**Characteristic:** with timer, automatically drain at settled time. Widely used in filter machine, separator, air tank, dripping feet and other air compressor system parts. Drain lasting time and separation time is adjustable.

**Medium:** Air , water

**Fluid Temp:** NBR: -5°C ~ 80°C

EPDM: -5°C ~ 100°C

VITON: -5°C ~ 120°C

**Pressure:** 0-1.6 Mpa

**Port size:** 1/2"

**Thread:** G thread

**Orifice:** 3.0mm

**Voltage:** DC-12V, 24V

AC-24V, 120V, 240V/60HZ; 110V, 220V/50HZ

**Tolerance:** ±10%

**Coil:** S11B, 24VA (AC) , 18W (DC) , IP65, 100%ED

**Material:** Body-Brass

Seal-NBR, EPDM, VITON

Tube-SS 304

Plunger-SS430F



Stop-SS430F

Spring-SS304

Shading rings-red copper



**Coils Parameters**


Model	Picture	Voltage	Motor Power	Protection Class	Outline Size Drawing
S21B		1.AC220V 2.AC110V 3.AC24V  1.DC24V 2.DC12V 3.DC6V  Special voltage can be customized	24VA18W	IP65	

**Specification of The Timer**



MODEL	KLT-R
Power Supply Voltage	24~380V AC/DC-50HZ/60Hz for "CE"Marked Timer
The Largest Current Consumption	4mA Max
Ambient Temperature	-10℃~+50℃
Water Proof Grade	IP65-EN 60529
Shell Material	Flame Retardant Abs Plastic
Time Interval(OFF)	From 0.5 to 10s.
Discharge Time (NO)	From 0.5 to 45min
Indicator Lamp	Yellow LED
Manual Test Button	Test
Electrical Connection	DIN43650A

**Outline Size Drawing**




**installation instructions**

- Two position,two way,normal close switch,magnetic solenoid water valve
- Can be installed any angle,but it is a good coice when the horixontal tube keep upward
- Used to control automatically the liquid and gas in the pipeline

**Safety instructions before starting**

1. Check the compatibility of the medium used, temperature and other operating conditions with the materials and specifications of the product. It is the responsibility of the user to select the right product for the application.
2. Solenoid valves can only be used with clean liquids or gases. It is recommended to install a filter before the solenoid valve.
3. Never exceed the limits for pressure, temperature or voltage as indicated on the product and/or in the technical documentation.
4. The temperature of a solenoid valve coil can rise during operation; this is normal. Overheating will cause smoke and a burning smell. In this case, the power supply must immediately be disconnected.

**▲** It is recommended to install the solenoid in vertical position with the coil facing upwards. This reduces the probability of the collection of debris in the solenoid valve.



**Installation Instruction**

1. The solenoid valve can be used in combination with clean liquids or gases. Make sure that the pipe may contain dirt before installing the valve. It is recommended to install a filter (500 µm) before the solenoid valve.
2. Be aware of the direction of flow of the medium when installing the valve. Solenoid valves with an arrow on the housing must be connected in the indicated direction. The pipes on both sides of the valve must be securely fastened. Use a wrench for both valve and pipe while tightening to prevent unnecessary stresses in the system. The solenoid valve must be fixed via the provided connection points. Only exert force at the designated areas on the body such as the hexagon; never to the coil or armature. Avoid vibration in the pipes. Use a suitable sealant for threaded connections of the solenoid valve. Avoid the entry of thread sealing material in the valve, this can lead to malfunctioning of the valve.

**Common faults and inspection, troubleshooting**

Problem	Solution
Valve fails to operate	1. Check electrical supply with voltmeter. Voltage must agree with nameplate rating.
	2. Check coil with ohmmeter for shorted or opened coil.
	3. Make sure that pressure complies with nameplate rating.
The valve is sluggish or inoperative - electrical supply and pressure check out	1. Disassemble valve; clean out extraneous matter. The plunger must be free to move without binding.
	2. If a diaphragm design, check the diaphragm for tears and/or clogged or obstructed bleed hole or pilot orifice. Torn diaphragm must be replaced.
	3. Check all springs. If broken, replace.
External leakage at sleeve flange or joint between body and cover	Check that the sleeve and/or cover screws are torqued to specifications. If leakage persists, replacement of diaphragm assembly or flange O-ring may be required and/or bodies or covers with damaged sealing surfaces may have to be replaced.
External leakage at speed control device	Check O-rings for damage and replace if necessary.
Internal leakage	1. Disassemble valve, remove extraneous matter, and clean parts in a mild soap and water solution.
	2. Examine diaphragm sealing surface for dirt. Remove all foreign particles. Examine orifice for nicks. Damaged parts must be repaired or replaced.
	3. Check plunger return spring. Replace if broken.
Chatter or buzz sound when energized	1. Remove power from the coil.
	2. Inspect the plunger and sleeve for excessive wear or contamination.